




BW-AH425C Series

**High precision CAN Bus Attitude
Heading Reference System**

Technical Manual



Introduction

BW-AH425C is a high-precision attitude heading reference system independently developed and produced by Bewis Sensing. It has built-in high-precision accelerometers, gyroscopes and magnetometers. It provides reliable heading and roll angle for motion carriers through multi-sensor fusion algorithms, pitch angle, angular velocity, acceleration and other information. The attitude data deviation is estimated by 6-state Kalman filter with appropriate gain, which is suitable for navigation, positioning and dynamic attitude measurement of unmanned vehicles. BW-AH400C adopts high-quality and reliable MEMS devices, and it ensures the measurement accuracy through temperature compensation and zero-drift correction algorithm. At the same time, the sealing design and strict production process ensure that it can still work reliably in harsh environments. BW-AH400C has a digital interface, which can be easily integrated into the user's system. This product is widely used in assisted driving, unmanned vehicles, drones, robots, and underwater equipment.

Feature

- Heading accuracy: 0.3°
- Dynamic and static accuracy
- Small size: L60 x W59 x H29 (mm)
- CAN interface output
- Wide temperature work: $-40^{\circ}\text{C} \sim +85^{\circ}\text{C}$, Temperature compensation
- Inclination accuracy: 0.2°

Application

- Satellite tracking
- Unmanned vehicle
- Stable platform
- Underwater Robot Navigation
- Drilling equipment monitoring and control
- Marine Surveyor
- Robot control



Electrical index

Power supply	9-35V DC
Working current	30mA (40mA max)
Operating temperature	-40~85°C
Storage temperature	-55~100°C



Performance index

Attitude parameter	Pitch/Roll accuracy	0.2°
	Heading accuracy	0.3°
	Inclination range	Pitch±90°, Roll±180°
Gyro	Resolution	0.01°
	Range	±400°/sec
	Zero Bias Stability at full temperature	10 °/h (10s, 1σ)
	ARW	< 0.1 °/√h
	Scale factor nonlinearity	≤100ppm (1σ)
	Scale factor repeatability	≤100ppm (1σ)
	Bandwidth	100Hz
Accelerometer	Range: X,Y,Z	±3.6 g
	Bias stability	0.001mg (25°C, 100s, 1σ) 0.01mg (25°C, 10s, 1σ)
Interface feature	Communication mode	CAN
	Maximum output frequency	100Hz
MTBF	≥90000 h/time	
EMC	According to GBT17626	
Insulation resistance	≥100 MΩ	
Impact resistance	2000g, 0.5ms, 3 time/axis	
Weight (with cable)	280g	

Resolution: The smallest change in the measured value that the sensor can detect and distinguish within the measurement range.

Accuracy: The root mean square error of the actual angle and the sensor measurement angle measured multiple times (≥16 times).





Mechanical properties

Connector	Metal joint (cable 1.5m)
Protection level	IP67
Shell material	Magnesium aluminum alloy anodizing
Installation	Four M4 screws




Package product size

Product size: L60*W59*H29 (mm)



PCBA Size


Product size: L44*W35*H11 (mm) There may be ± 1 mm error in length and width, please refer to the actual product




Installation

The correct installation method can avoid measurement errors. When installing the sensor, please do the following:

First of all, make sure that the sensor mounting surface is completely close to the measured surface, and the measured surface should be as level as possible. There should be no included angles as shown in Figure A and Figure C. The correct installation method is shown in Figure B and Figure D.



Secondly, the bottom line of the sensor and the axis of the measured object cannot have an angle as shown in Figure E, and the bottom line of the sensor should be kept parallel or orthogonal to the axis of rotation of the measured object during installation. This product can be installed horizontally or vertically (vertical installation needs to be customized), and the correct installation method is shown in Figure F.



Finally, the mounting surface of the sensor and the surface to be measured must be tightly fixed, smooth in contact, and stable in rotation, and measurement errors due to acceleration and vibration must be avoided.

Measurement installation

Although the AH400C can compensate for magnetic interference, users should choose an environment with the least magnetic interference to install and use. As far as possible, choose to place it away from iron, nickel, magnets, motors and other magnetic materials.

Be sure to strictly avoid strong magnetic materials such as magnets and motors from approaching the product, which may cause irreversible degradation of the product's measurement accuracy.

Each AH400C provides a 1.5-meter cable, and the length of the cable is optional. The magnetic field environment of each installation location is different, and the user must evaluate the feasibility of installation in this operating environment.

The test method we recommend is to install the AH400C on a vertically erected aluminum (or other non-magnetic material) pole to measure the heading accuracy (the rotating pole is perpendicular to the rotating platform, and try to avoid large external magnetic field interference).

Calibration

The product has been calibrated in the factory. In places where the magnetic field environment has little influence, there is no need to perform environmental calibration during use, and it can be used directly. In actual use, it is recommended to calibrate.

Azimuth calibration steps:

Method 1——Plane calibration

1. Connect the product to the system and place the product in a horizontal state;
2. Open the serial port debugging assistant, send 77 04 00 11 15, and return to 77 05 00 91 00 96 to start plane calibration;
3. Rotate the product in the horizontal plane (both pitch and roll angles are within $\pm 5^\circ$) around the z-axis (z-axis is the vertical direction), and rotate 2-3 times. The rotation process should be as slow and close as possible. Rotate at a constant speed, and the time for one revolution is controlled between 10 seconds and 15 seconds;
4. Rotate the compass around the X-axis or Y-axis. The rotation process can be slow and nearly uniform. It rotates 2-3 times around each axis, and the time for one rotation is about 15 seconds;
5. After completing the calibration, send 77 04 00 12 16 to save the calibration, and return to 77 05 00 92 XX SUM (the data field is meaningless), the calibration is successful.

Method two-multi-faceted calibration

1. Fix the product in the use environment, and try not to carry magnetic objects such as keys and mobile phones during calibration;
2. Place the product in a horizontal state (within $\pm 5^\circ$);
3. Send the following calibration command in hexadecimal format: 77 04 00 08 0C, the return value is 77 05 00 88 00 8D;
4. The product is placed in a horizontal state, the front is facing upwards (both pitch and roll are within $\pm 5^\circ$), the myopia rotates one circle at a constant speed, and it takes more than 10 seconds to rotate one circle;
5. The product is placed in a horizontal state, the installation surface is facing upwards (the pitch is within 0 ± 5 degrees, the roll is within 180 ± 5 degrees), the myopia rotates one circle at a constant speed, and it takes more than 10 seconds to rotate one circle;

6. The product is placed in a vertical state, with the smooth side of the shell facing down (pitch within 0 ± 5 degrees, roll within 90 ± 5 degrees), and the myopia rotates one circle at a constant speed, and it takes more than 10 seconds to rotate one circle;

7. The product is placed in a vertical state with the other smooth side of the shell facing downwards (pitch within 0 ± 5 degrees, roll within -90 ± 5 degrees), and the myopia rotates one circle at a constant speed, and it takes more than 10 seconds to rotate one circle;

Among them, step 4.5.6.7 can be exchanged;


8. After the four faces are rotated, send the hexadecimal command 77 04 00 09 0D to save the calibration and return to 77 05 00 89 XX YY. Where XX represents the calibration error coefficient, the smaller the value is, the better, less than 10 is ideal, FF represents the calibration failure, YY is the checksum of the command;

9. The calibration is complete.

Electrical interface

Wiring definition

	RED	BLUE	BLACK	GREEN	YELLOW
Wire color	1	2	3	4	5
function	VCC DC 9-35V	NC	GND	CAN L	CAN H



CAN Bus Wiring Diagram

Order information

Product model	Communication mode	Package situation
BW-AH425C-CAN	CAN	IP67 package/Metal joint

Executive standard

- Enterprise Quality System Standard: ISO9001:2015 Standard (Certificate No.064-21-Q-3290-RO-S)
- CE certification (certificate number: M.2019.103. U Y1151)
- ROHS (certificate Number: G 190930099)
- GB/T 191 SJ 20873-2003 General specification for inclinometer and level
- GBT 18459-2001 The calculation method of the main static performance index of the sensor
- JJF 1059.1-2012 Evaluation and expression of measurement uncertainty
- GBT 14412-2005 Mechanical vibration and shock Mechanical installation of accelerometer
- GJB 450A-2004 General requirements for equipment reliability
- GJB 909A Quality control of key parts and important parts
- GJB899 Reliability appraisal and acceptance test
- GJB150-3A High temperature test
- GJB150-4A Low temperature test
- GJB150-8A Rain test
- GJB150-12A Sand and dust experiment
- GJB150-16A Vibration test
- GJB150-18A Impact test
- GJB150-23A Tilt and rock test
- GB/T 17626-3A Radio frequency electromagnetic field radiation immunity test
- GB/T 17626-5A Surge (impact) immunity test
- GB/T 17626-8A Power frequency magnetic field immunity test
- GB/T 17626-11A Immunity to voltage dips, short-term interruptions and voltage changes

BW-AH425C Series

**High-precision CAN Attitude
Heading Reference System**

Wuxi Bewis Sensing Technology LLC

Add: Building 30, NO. 58, Xiuxi Road, Binhu District,
Wuxi City, Jiangsu Province, China

Tel: +86 18921292620

Mail: sales@bwsensing.com

Web: www.bwsensing.com